



# Health Care Call System

## Staff Emergency Station

Cat. 6431

### DESCRIPTION

Jeron Staff Emergency Stations are used to allow staff to call for immediate assistance.

- Positive Detent Action

### OPERATION

Pressing the top of the button activates all system call signals for an urgent level call.

The panel indicator lights to verify that a call has been placed.

Staff Emergency calls must be canceled at the originating station by pressing the bottom of the button.

### EQUIPMENT

Stations are furnished with a CALL button, amber call LED and 'STAFF EMERGENCY' label on a modular green plastic subplate for flush wall mounting with included white plastic trimplate.

The low profile pushbutton has a positive detent rocker action to resist accidental or partial operation. Panels resist common hospital cleaning agents.



### ARCHITECTS/ENGINEERS SPECIFICATIONS

Staff Emergency Stations shall be Jeron Cat. 6431 with a low profile pushbutton having positive detent action, an amber call placed LED on a modular green subplate with separate plastic faceplate for flush wall mounting. Staff emergency calls shall be canceled at the originating station only.

### TECHNICAL DATA

#### Mounting:

- White thermoset plastic 1-gang trimplate with separate green modular subplate and matching plastic hardware

#### Dimensions (H x W x D):

- 4.5 x 2.75 x 2.5 in.  
(11.4 x 7 x 6.4 cm)

#### Back-box Required:

- Raco 670RAC 1-gang mounted 1/2" behind wall face or Raco 232 2-gang with Raco 772 1-gang raised cover

#### Controls/Indicators:

- CALL Pushbutton: Black, molded thermoplastic
- Call placed indicator: Amber LED

#### Operating Voltage:

- 28 VDC

#### Field Connections:

- Plug-in IDC block; Connector provided

#### Certification:

- UL 1069 Listed
- C-UL — Canadian Standard C22.2 NO.125

PRODUCT SUBJECT TO CHANGE WITHOUT NOTIFICATION.