



Health Care Call System

Pullcord Bath Station

Cat. 6432

DESCRIPTION

Jeron Pullcord Bath Stations are used to signal the Nurse Master Station from a bath or similar location.

OPERATION

Pulling the cord from any angle activates all system call signals for an urgent level call. The station's LED indicator illuminates to verify that a call has been placed.

Bath calls must be canceled at the originating Bath Station by sliding the reset switch upwards.

EQUIPMENT

Stations are furnished with pullcord, reset switch, LED call placed indicator and are engraved with a 'PULL FOR HELP' 1/8" high label on a stainless steel trimplate for flush wall mounting. Panels resist common hospital cleaning agents. Replacement pullcords are available.



ARCHITECTS/ENGINEERS SPECIFICATIONS

Pullcord Bath Stations shall be Jeron Cat. 6432 1-gang with six foot white nylon pullcord, reset switch, red call placed LED and engraved 'PULL FOR HELP' label on a stainless steel faceplate for flush wall mounting.

Bath calls shall be canceled at the originating Bath Station only.

TECHNICAL DATA

Mounting:

- Brushed stainless steel 1-gang faceplate with plated steel mounting hardware

Dimensions (H x W x D):

- 4.5 x 2.75 x 2.5 in.
(11.4 x 7 x 6.4 cm)

Back-box Required:

- Raco 670RAC 1-gang mounted 1/2" behind wall face or Raco 232 2-gang with Raco 772 1-gang raised cover

Controls/Indicators:

- Pullcord: 6 ft. (1.8 m) braided, white, nylon cord with white, nylon pendant and metal cord guide with plastic shroud
- Reset Switch: Slide action
- Call Placed Indicator: Red LED

Operating Voltage:

- 28 VDC

Field Connections:

- Plug-in IDC block

Certification:

- UL 1069 Listed
- C-UL — Canadian Standard C22.2 NO.125

PRODUCT SUBJECT TO CHANGE WITHOUT NOTIFICATION.