

Auxiliary Alarm Station

Cat. 6443

DESCRIPTION

The Jeron Alarm Interface is used to interface a Nurse Call System with a set of external alarm contacts.

OPERATION

When the external contacts are closed, an alarm call will be placed on the system.

EQUIPMENT

The Alarm Interface is furnished on a white, flame-retardant, modular one-gang subplate for flush wall mounting with a separate thermostat trimplate. Panels resist common hospital cleaning agents.



TECHNICAL DATA

Mounting:

- White, flame-retardant, modular, 1-gang subplate with separate thermostat trimplate and matching plastic hardware

Dimensions (H x W x D):

- 4.5 x 2.75 x 2.2 in.
(11.4 x 7 x 5.6 cm)

Back-box Required:

- Raco 670RAC 1-gang mounted 1/2" behind wall face *or* Raco 232 2-gang with Raco 772 1-gang trim ring

Operating Voltage:

- 28 VDC @ 10 mA

Field Connections:

- Plug-in IDC block

PRODUCT SUBJECT TO CHANGE WITHOUT NOTIFICATION.