



Health Care Call System

P.A. Page Control Cat. 6816

DESCRIPTION

Jeron P.A. Page Controls are used to interface the Nurse Master Station(s) to external public address page systems or to an all-call page amplifier.

OPERATION

The Nurse Master Station attendant selects the appropriate page zone from an on-screen menu, depresses the PAGE button, and speaks to make an announcement over the selected page system.

EQUIPMENT

The P.A. Page Control is furnished on a two-gang modular subplate for flush wall mount with a separate trimplate. Ganging with other station subplates in a common opening may be accomplished by using Cat. 6803-6806 Multi-gang Adapter Trimplates.



TECHNICAL DATA

Mounting:

- White thermoset plastic 2-gang trimplate with separate modular subplate and matching plastic hardware

Dimensions (H x W x D):

- 4.5 x 4.5 x 2.5 in.
(11.4 x 11.4 x 6.4 cm)

Back-box Required:

- Raco 951 2-gang box with 821 2-gang raised cover

Amplifier Interface:

- One N.O. contact set for amplifier mute;
One balanced audio pair

Operating Voltage:

- 28 VDC

Field Connections:

- Plug-in IDC block;
Connector provided

Certification:

- UL 1069 Listed
- C-UL — Canadian Standard C22.2 NO. 125

PRODUCT IS SUBJECT TO CHANGE WITHOUT NOTIFICATION